



# 2 NODE SMART MODULE SERIES #SwitchToSmart



#### DESCRIPTION

The 2 Node insert module is a combination of Relay & Curtain Control. By just adjusting the toggle switch, one can easily customize its mode of operation to enable you to control:

- EITHER any 2 of your relay switches (ON/OFF)
- OR your curtain/roller shades











VOICE CONTROL


# SPECIFICATIONS

Model Number	HC-IM-2I-IN
Power Requirement	AC 110-230V, 50-60Hz.
Dimensions	37x37x18.3 mm
Load Rating	Max 300w for resistive loads, 150w for Capacitive loads, 200w for inductive load
Operating Temperature	32°F - 104°F or 0°C - 40°C
Humidity	0-90%
Storage	-4°F to 158°F or 20°C to 70°C
Wireless Range	50m Outdoor – 20m Indoor
Radio Protocol	Z-Wave Plus
Radio Signal Power	lm
Radio Frequency	EU - 868.40/869.40 MHz IN - 865.20 MHz BR/AU - 919.80/ 921.40 MHz US - 908.40/ 916/ 908.49 MHz
The Relay	Тwo
Curtain Control	One

# PRE INSTALLATION MANDATORY CHECKS

- It is always advised to consult a certified electrician to perform the installation process.
- Ensure the Load capacity & Power requirements of your intended switch matches the technical specifications.
- Ensure you follow all national and local electrical codes for installation.
- $\bullet$  **TURN OFF** the mains to make sure no power is running. You may check the same by using an inductive voltage detector
- Open the Wall Switch/Faceplate. You may use a flathead screwdriver to open the switch gently.

# INSTALLATION



### CONFIGURATION TO ZWAVE CONTROLLER

1. Set the controller into inclusion mode (Refer controller's manual for instructions)

- 2. Turn ON the mains.
- 3. Press and Hold config button for 5-7 seconds till **LED** blinks **BLUE** & then release.

4. On successful addition of the device, the controller sends a confirmation.

#### WARRANTY

Hogar Provides Limited Warranty of 18 months on every product.

#### ENQUIRY

For Orders/Details, kindly reach out to us at info@hogarcontrols.com



Scan QR code for more details on warranty and sales enquiries