



# **GAS SMART SENSOR SERIES** #SmartSense



#### DESCRIPTION

The Gas Sensor enables you to detect any inadvertent gas leakage in your home and trigger alarms in time to help you take the necessary precautions.

LED SIGNAL	SOUND	WHAT IT MEANS
RED LED ON	Buzzer Sound	Gas Leakage Alarm
RED GREEN & YELLOW LED flashing alternately	No Sound	Gas Sensor Warming Up
GREEN LED ON	No Sound	Normal Working mode
YELLOW LED ON	Buzzer Sound	False Alarm













#### **SPECIFICATIONS**


LINKAGE TO OTHER

Model No.	HSE-GAS-001
Battery Type	CR2450
Power Requirement	12V DC Adapter
Alarm Current	<= 150 μAT
Dimensions	66 x 66 x 29 mm
Operating Temperature	−10° C − +55 °C
Humidity	0 - 95%
Wireless Protocol	ZigBee 3.0
Alarm Sound	> 70 DB (front lm)
Alarm Method	Sound & light alarm, wireless networking alarm
Detection Gas Type	Natural Gas (CH₄)

### INSTALLATION

· Gas Sensor can be installed on your ceiling either by screwing it on or by using a 3M tape. Screw Installation is ALWAYS preferred.

#### **SCREW MOUNTING**



#### 3M GLUE



#### ADDING GAS SENSOR TO YOUR HOME

- Open the Hogar SE App and go to "Rooms".
- Click on "+" Button and select "Gas Sensor". Follow the prompts on your App for subsequent operations.
- To turn on the Power Source, open the front cover of your Gas Sensor by turning it **COUNTERCLOCKWISE** & plug in the adapter DC plug.
- To POWER ON the Gas Sensor, Press and Hold the button for 5 seconds.
- You will soon see the GREEN LED flash that indicates that the Gas Sensor is now in the Enroling Mode.
- · Click on "Confirm Indicator Rapidly Blink" on your Hogar SE App.



• Your Gas Sensor is now successfully added to your Hogar SE App.

## WARRANTY

Hogar Provides Limited Warranty of 18 months on every product.

#### **ENQUIRY**

For Orders/Details, kindly reach out to us at info@hogarcontrols.com



Scan QR code for more details on warranty and sales enquiries