



CEREBRO PRO SMART HOME HUB

DESCRIPTION

The Cerebro Pro (Referred to as HC Pro V2) connects devices to the network and controls communication among them. The Cerebro Pro connects either locally or to the cloud and allows you to control your smart home devices via the Hogar pro app.

The Hogar Pro app allows you to receive alerts/notifications about the connected devices and run your home remotely with the mobile device. The Hub receives commands from the app and sends to other devices, also the important alerts to your mobile device if some action occurs.







PLUG AND PLAY

MULTI PROTOCOL

SECURE SHELL





APP CONTROL

SEAMLESS CONNECTIVITY

SPECIFICATIONS

Model number	HC-02-VV
Power requirement	AC 110/230V 50-60
CPU	Quad-core ARM®
RAM & ROM	512MB & 4GB eMMC
Setup	Hogar Pro App
Number of Z-wave Devices support per controller	232
Encryption Security level	S2
Wireless specifications	
Internet Connectivity	Wi-Fi, Ethernet, 3G/4G USB Modem
Wireless Range	50m outdoor - 30m indoor
Radio protocol	Z-Wave Plus, Zigbee 3.0, BLE, WIFI

PREINSTALLATION & CHECKS:

- Avoid pressing hard on the device body, reset button, and connecting ports.
- Make sure you are connected with internet before installation
- Kindly take care of the distance between the devices as range and performance depend on it

HC PRO CONFIGURATION

There are 2 ways to configure the Home Controller to the internet:

Registering your Cerebro Pro:

- 'Select Home' & Tap the "+" button in the top right corner of the screen.
- Click on Add Home →Home Name → Domain Name → Save.
- · Add new master HC to home.
- · Select "HC has no internet connection".
- The HC generates a Hotspot automatically, then connects to the HOGARHC_XXXX & gets back to Hogar Pro APP.
- Select "Yes, I Connected" and follow the steps to set up the HC pro V2

Please consult the manual to add the HC Pro to your home and configure floors, rooms & scenes

Ethernet Configuration:

- · Connect the Cerebro pro to an electrical outlet.
- Plug-in Ethernet cable to Cerebro Pro.
- Choose "LAN "in the connection type page.
- By default, the DHCP is active, and the parameters are automatically set.
- If you want to set a static IP, choose static and fill in the required details manually and tap done.

Wi-fi Configuration:

- · Connect the Cerebro pro to an electrical outlet.
- Choose "Wi-Fi "in the connection type page.
- Choose a Wi-Fi SSID & Enter the required password and connect to the network.
- Click the checkbox (static) and enter Gateway, DNS, and IP details.

APP INFORMATION

Cerebro Pro supports Hogar Pro App and works seamlessly by integrating with all other Smart Home Devices. With the user-friendly Hogar Pro App; the user can run Cerebro Pro to check summaries, schedule the events, receive alerts, assign rules, monitor, and control the smart home.









WARRANTY & ENQUIRY

Hogar provides a limited warranty of 18 months on every

For Orders/Details, kindly reach out to us at info@hogarcontrols.com



Scan QR code for more details and Sales enquiries