



VIBRATION SMART SENSOR SERIES

#SmartSense



DESCRIPTION

The Door/Window Sensor detects & emits wireless signals on the opening & closing of your doors/windows. This can be used as an alert on your Hogar SE App and to trigger & automate multiple other smart devices connected to your Hogar SE Gateway & App.

The Door/Window Sensor uses the principle of magnetic control and triggers a Wireless signal as soon as the magnet is seperated from its main body by a certain distance (about **20mm**)













SPECIFICATIONS

Model No.	HSE-VS-001
Battery Type	CR2032
Static Current	<= 10 μA
Main Body Size	58 x 36 x 15 mm
Operating Temperature	–10 °C to 55 °C
Humidity	0 - 95% RH
Wireless Protocol	ZigBee 3.0
Transmit Frequency	2.4000 - 2.4835 GHz

INSTALLATION

- Tear off the centrifugal paper from 3M adhesive and fix the Vibration Sensor in the desired position with the 3M adhesive.
- Ensure the surface on which the Vibration Sensor is installed is smooth, especially if it is glass mounted, so that it does not fall.





ADDING VIBRATION SENSOR TO YOUR HOME

- Open the Hogar SE App and go to "Rooms".
- Click on "+" Button and select "Vibration Sensor". Follow the prompts on your App for subsequent operations.
- To **POWER ON** the Vibration Sensor, **press and hold** the Reset Button for **5 seconds**.
- You will soon see the **GREEN LED** flash that indicates that the Vibration Sensor has entered into "Enrolling Mode".



- Click on "Confirm Indicator Rapidly Blink" on your Hogar SE App.
- Your Vibration Sensor is now successfully added to your Hogar SE App

WARRANTY

Hogar Provides Limited Warranty of 18 months on every product.

ENQUIRY

For Orders/Details, kindly reach out to us at info@hogarcontrols.com



Scan QR code for more details and Sales enquiries